
OPERATOR & MAINTENANCE INSTRUCTIONS

RA-300

ADVANCED RAM AIR PARACHUTE SYSTEM

8327XX-X



WARNING: This document contains technical data whose export is restricted by the Arms Export Control Act (Title 22, U.S.C., Sec 2751, et. Seq.) or the Export Administration Act of 1979, as amended, Title 50A, U.S.C., App. Violations of these export laws are subject to severe criminal penalties. Disseminate in accordance with provisions of DOD Directive 5230.25.

DESTRUCTION NOTICE: Destroy by any method that would prevent Disclosure of content or reconstructions of the document.

RECORD OF CHANGES

| CHANGE NO. | DATE | TITLE OR BRIEF DESCRIPTION | ENTERED BY |
|------------|-------------------|--|-------------------|
| Issue 1 | 12 February 2015 | RA-300 Advanced Ram Air Parachute System Operator and Maintenance Manual 8327xx-x | Kenneth W. George |
| Issue 1 | 12 March 2015 | Added main closing loop install procedures and reduced picture sizes | Kenneth W. George |
| Issue 1 | 22 September 2015 | Condensed TM by removing duplicate packing procedures and some blank pages. Converted spares packages to spares, maintenance, expendables packages. | Kenneth W. George |
| Issue 2 | 22 September 2016 | Updated instructions for reserve deployment bag and bridle design. Removed warning summary, acronyms and abbreviations. Added SOLR O2 bottle assembly procedures. Changed steering toggle attachment procedures. | Kenneth W. George |