
OPERATOR & MAINTENANCE INSTRUCTIONS

PHAOS S88
(PARACHUTIST'S HIGH ALTITUDE OXYGEN
SUPPLY SINGLE 88)
BAILOUT BOTTLE

603100-0



WARNING: This document contains technical data whose export is restricted by the Arms Export Control Act (Title 22, U.S.C., Sec 2751, et. Seq.) or the Export Administration Act of 1979, as amended, Title 50A, U.S.C., App. Violations of these export laws are subject to severe criminal penalties. Disseminate in accordance with provisions of DOD Directive 5230.25.

DESTRUCTION NOTICE: Destroy by any method that would prevent Disclosure of content or reconstructions of the document.

RECORD OF CHANGES

| CHANGE NO. | DATE | TITLE OR BRIEF DESCRIPTION | ENTERED BY |
|------------------|------------------|--|-------------------|
| Original Issue 1 | 12 March 2013 | PHAOS S88 (Parachutist's High Altitude Oxygen Supply Single 88) Bailout Bottle 603100-0 Operator and Maintenance Manual. | Kenneth W. George |
| Issue 1 | 20 May 2013 | Revised Illustrated Parts Breakdown. | Kenneth W. George |
| Issue 2 | 26 February 2014 | Removed HDT Logo, Added spare parts list. | Kenneth W. George |