

---

**OPERATOR & MAINTENANCE INSTRUCTIONS**

**RA-1**

**ADVANCED RAM AIR PARACHUTE SYSTEM**

**11-1-9100**



**WARNING:** This document contains technical data whose export is restricted by the Arms Export Control Act (Title 22, U.S.C., Sec 2751, et. Seq.) or the Export Administration Act of 1979, as amended, Title 50A, U.S.C., App. Violations of these export laws are subject to severe criminal penalties. Disseminate in accordance with provisions of DOD Directive 5230.25.

**DESTRUCTION NOTICE:** Destroy by any method that would prevent Disclosure of content or reconstructions of the document.

**RECORD OF CHANGES**

<b>CHANGE NO.</b>	<b>DATE</b>	<b>TITLE OR BRIEF DESCRIPTION</b>	<b>ENTERED BY</b>
Issue 1	22 July 2014	RA-1 Advanced Ram Air Parachute System Operator and Maintenance Manual 11-1-9100	Kenneth W. George
Issue 1	12 March 2015	Added main closing loop install procedures to Chapter 3.	Kenneth W. George
Issue 1	22 September 2015	Condensed TM by removing duplicate packing procedures and some blank pages. Converted spares packages to spares, maintenance, expendables packages.	Kenneth W. George
Issue 2	13 July 2017	Removed warning summary, acronyms and abbreviations. Added PRO packing instructions for reserve and double bag static line, Updated and corrected procedures.	Kenneth W. George