
OPERATOR AND MAINTENANCE LEVEL 2

**INSTRUCTION
SOLR[®] 3000
122 CU. IN. BAILOUT BOTTLE
603828-0**



WARNING: This document may contain technical data whose export is restricted by the Arms Export Control Act (Title 22, U.S.C., Sec 2751, et seq.) or the Export Administration Act of 1979, as amended, Title 50, U.S.C., App. 2401 et seq. Violations of these export laws are subject to severe criminal penalties. Disseminate in accordance with provisions of DoD Directive 5230.25.

DESTRUCTION NOTICE: Destroy by any method that would prevent Disclosure of content or reconstructions of the document.

RECORD OF CHANGES

Go to <https://airborne-sys.com/riggers-corner/> see if your technical manual is the most current by searching for the manual and reviewing the record of changes page. Some revisions may not require a new manual. Contact your Airborne Systems sales associate for assistance in getting an updated technical manual.

| CHANGE NO. | DATE | TITLE OR BRIEF DESCRIPTION | ENTERED BY |
|-------------------|---------------|--|-------------------|
| Original issue 1 | 2 August 2018 | Level 2 Service for SOLR® 3000 Bailout Bottle Maintenance Instructions | Oliver K. Frazier |