

OPERATOR INSTRUCTIONS 10K PACK TOWER 836708-0



<u>WARNING:</u> This document contains technical data whose export is restricted by the Arms Export Control Act (Title 22, U.S.C., Sec 2751, et. Seq.) or the Export Administration Act of 1979, as amended, Title 50A, U.S.C., App. Violations of these export laws are subject to severe criminal penalties. Disseminate in accordance with provisions of DOD Directive 5230.25.

 $\underline{\textbf{DESTRUCTION NOTICE:}} \ \text{Destroy by any method that would prevent Disclosure of content or reconstructions of the document.}$

ISSUE 1 10 NOVENBER 2016

10K PACK TOWER TM0070-1

RECORD OF CHANGES

| CHANGE NO. | DATE | TITLE OR BRIEF DESCRIPTION | ENTERED BY |
|---------------|------------------|--|-------------------|
| Original | November 2016 | Users Guide for the Airborne Systems 10K Packing Tower | Michael J. Thorn |
| Issue 1 | 10 November 2016 | 10K Pack Tower 836708-0 Operators Instructions | Kenneth W. George |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |

836708-0 I

TM0070-1 10K PACK TOWER

INTENTIONALLY BLANK

II 836708-0