

---

**OPERATOR & MAINTENANCE INSTRUCTIONS**

**FOR THE  
T-11R  
T-11 RESERVE  
PARACHUTE SYSTEMS**



**WARNING:** This document contains technical data whose export is restricted by the Arms Export Control Act (Title 22, U.S.C., Sec 2751, et. Seq.) or the Export Administration Act of 1979, as amended, Title 50A, U.S.C., App. Violations of these export laws are subject to severe criminal penalties. Disseminate in accordance with provisions of DOD Directive 5230.25.

**DESTRUCTION NOTICE:** Destroy by any method that would prevent Disclosure of content or reconstructions of the document.

**© COPYRIGHT NOTICE**

This T-11 Reserve Parachute Systems technical manual is protected by U.S. and International copyright laws. Reproduction and distribution of the information within this technical manual without written permission from Airborne Systems North America Inc. is prohibited.

**RECORD OF CHANGES**

Go to <https://airborne-sys.com/riggers-corner/> to see if your technical manual is the most current by searching for the manual and reviewing the record of changes page. Some revisions may not require a new manual. Contact your Airborne Systems sales associate for assistance in getting an updated technical manual.

<b>CHANGE NO.</b>	<b>DATE</b>	<b>TITLE OR BRIEF DESCRIPTION</b>	<b>ENTERED BY</b>
Original Issue 1	7 March 2019	T-11R T-11 Reserve Parachute Systems Operators & Maintenance Instructions.	Kenneth W. George
Issue 2	11 March 2021	New extractor assembly instructions	Kenneth W. George