
OPERATOR AND MAINTENANCE LEVEL 2

**INSTRUCTION
SOLR[®] 3000
122 CU. IN. BAILOUT BOTTLE
603828-0**



WARNING: This document may contain technical data whose export is restricted by the Arms Export Control Act (Title 22, U.S.C., Sec 2751, et seq.) or the Export Administration Act of 1979, as amended, Title 50, U.S.C., App. 2401 et seq. Violations of these export laws are subject to severe criminal penalties. Disseminate in accordance with provisions of DoD Directive 5230.25.

DESTRUCTION NOTICE: Destroy by any method that would prevent Disclosure of content or reconstructions of the document.

RECORD OF CHANGES

Go to <https://airborne-sys.com/riggers-corner/> see if your technical manual is the most current by searching for the manual and reviewing the record of changes page. Some revisions may not require a new manual. Contact your Airborne Systems sales associate for assistance in getting an updated technical manual.



Scan for Record of Changes

CHANGE NO.	DATE	TITLE OR BRIEF DESCRIPTION	ENTERED BY
Original issue 1	2 August 2018	Level 2 Service for SOLR® 3000 Bailout Bottle Maintenance Instructions	Oliver K. Frazier
Issue 1	28 February 2019	Corrected TM number	Kenneth W. George
Issue 2	21 October 2022	Added Mechanical Lock to Bailout Bottle, Added Replacement of the High Pressure Seat and Diaphragm, Replacement of C-Clip and Float Valve. Updated Torque Specs Added Part Numbers to Steps.	Oliver K. Frazier
Issue 2	24 February 2023	Added Export Control Stamp to all pages.	Oliver K. Frazier
Issue 3	08 March 2024	Removed replacement of High Pressure Seat and Diaphragm. Removed venting system. Updated Exploded Views. Updated Spares List. Updated Tool List. Added Scannable QR Codes.	Oliver K. Frazier