
OPERATOR & MAINTENANCE INSTRUCTIONS

FOR THE

T-11 GEN2 MAIN

PARACHUTE SYSTEM



WARNING: This document may contain technical data whose export is restricted by the Arms Export Control Act (Title 22, U.S.C., Sec 2751, et seq.) or the Export Administration Act of 1979, as amended, Title 50, U.S.C., App. 2401 et seq. Violations of these export laws are subject to severe criminal penalties. Disseminate in accordance with provisions of DoD Directive 5230.25.

DESTRUCTION NOTICE: Destroy by any method that would prevent Disclosure of content or reconstructions of the document.

© COPYRIGHT NOTICE

This T-11 Gen2 Main Parachute System technical manual is protected by U.S. and International copyright laws. Reproduction and distribution of the information within this technical manual without written permission from Airborne Systems North America Inc. is prohibited.

RECORD OF CHANGES

Go to <https://airborne-sys.com/riggers-corner/> to see if your technical manual is the most current by searching for the manual and reviewing the record of changes page. Some revisions may not require a new manual. Contact your Airborne Systems sales associate for assistance in getting an updated technical manual.

CHANGE NO.	DATE	TITLE OR BRIEF DESCRIPTION	ENTERED BY
Original Issue 1	29 November 2022	T-11E Main Parachute System Operators & Maintenance Instructions.	Kenneth W. George
Issue 1	20 February 2023	Added Export Control Stamp to all pages.	Kenneth W. George
Issue 2	11 July 2024	Updated packing procedures and pictures for T-11 with T-slits. Changed system to T-11 Gen2 Main Parachute System. Removed pictures in maintenance procedures. Increased maximum all up weight to 450 lbs.	Kenneth W. George
Issue 3	19 February 2025	Updated procedures, rigger checks, support kits, and format.	Kenneth W. George